

Lens Shifts



- Vertical shift of the lens possible between 15 mm (0.59") up and down without removing the projector cover.
- Horizontal shift of the lens possible between 5 mm (0.2") left and right without removing the projector cover.
- Shift of the displayed picture on the screen up till 1.4 meters up or down and 0.5 meters left or right over its standard position.
- The shift of the lensholder is not determined by the lens used, but depends on the screen width.
- Can be used with all available lenses.