


# ClickShare


## Is your video and audio peripheral set-up interoperable with ClickShare Conference?

### 3 configurations are possible



All-in-one device  
(camera and speakerphone in  
1 device with 1 USB output)

with USB 2.0



Set-up of 1 camera and 1  
speakerphone (integrated  
speaker and microphone)

with USB 2.0



DSP and mixers leveraging  
audio and/or video  
equipment

with USB 2.0


### Pay attention if:



Your device requires more power  
than USB-2.0?




Connect your device with  
a USB-C connector or via a  
powered USB hub.



You want to connect  
multiple devices?



Connect your devices via USB  
switch. Make sure only 1 camera  
and 1 speakerphone are active at  
any point in time.



You have  
an HDMI camera?



Use a HDMI to USB converter  
to connect your camera.

### We don't support:

- Separate microphone and speaker (even when connected via USB)
- Microphone in camera or in display (without being part of a speakerphone)
- Audio over HDMI when speakerphone connected

